

Windows:

Download drivers from Garland Technology's web site. (lan7800-wdf-v18.x.x.x.exe)

Double click the exe file

Agree to the End-User License Agreement and continue with the install. When complete, click Finish.

At this point, please plug in the USB Tap. (on some machines, a system reboot may be needed)

Going to Control Panel → Network and Sharing, there should be 2 new Ethernet interfaces:



In this case, the new interfaces are Ethernet 6 and Ethernet 7. These will be the interfaces seen in Wireshark.